

POWERCLEAN® PC 6500

RECHARGEABLE VACUUM CLEANER
CLEANING & MAINTENANCE

FILTER CLEANING

Periodic filter cleaning enhances product performance
and ensures long-lasting use

Press the button to detach the dust bin from the device 	Pull the filter upward to remove it, then lift the EPA filter and sponge upward to separate them from the metal filter 	Empty the dust from the dust bin 	Tap the metal filter gently to remove dust 
Gently tap the EPA filter to remove the dust. 	Wash the EPA filter and the sponge with lukewarm water, keeping the inner side facing down, and let them dry for 24 hours 	Once dry, reattach all parts back into the device 	

AIR OUTLET FILTER CLEANING

Press the button to detach the outlet filter from the device 	It should separate into two parts 	Tap the filter gently to remove dust 	Reattach the air outlet filter to the appliance 
--	--	--	--

TURBO BRUSH CLEANING

Press the button next to the brush, then slide out the roller brush cover 	Wash with warm water and let it dry for 24 hours 	Once dry, place the roller brush back into position 	
---	--	--	--

MINI TURBO BRUSH CLEANING

Use an object to turn and remove the roller brush cover 	Wash with warm water and let it dry for 24 hours 	Once dry, place the roller brush back into position 	Use an object to close the roller brush cover securely 
---	---	---	---